



Assembly

1. Connect the LED converter to the mains.
2. Connect the Dim Controller to the distributor of the converter.
3. Push the „Study Button“ in the receiver with a sharpen object such as screwdriver or refill for a ballpoint pen. The indicator lamp turns on blue.
4. Follow the instruction for the different remote controls on the other page.
5. After finish above steps, the indicator lamp is still on. It means learning is failed. Please repeat the process again.
6. The LED luminaires can now be controlled with the recessed radio telecontrol or remote control.

Point 3 - 6 are only necessary to adjust further receivers to the same radio telecontrol or remote control.

